




# ZENITH 1700

Quick Guide – Version 1.0



850W+850W @ 4Ω

Stereo, bridge & parallel modes

Input sensitivity selector

PowerCon supply connector

AC 100-240V 50/60Hz

## Amplifier 850W+850W @ 4Ω

### SAFETY INSTRUCTIONS

- Use the closed QR code to download the last user manual version from our website.
- Don't use this device close to the water or high humidity places. Clean only with dry cloth.
- Don't install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by WORK PRO
- Unplug this device during lightning storms or when unused for long periods of time.




51ZEN170



# ZENITH 1700

Guía Rápida – Versión 1.0



850W+850W @ 4Ω

Modos Estéreo, bridge y paralelo

Selector de sensibilidad de entrada

Conector PowerCon de alimentación

AC 100-240V 50/60Hz

## Amplificador 850W+850W @ 4Ω

### INSTRUCCIONES DE SEGURIDAD

- Use el Código QR adjunto para descargar la última versión del manual de usuario desde nuestro sitio web.
- No use este dispositivo cerca del agua o zonas altamente húmedas. A la hora de limpiarlo, utilice un paño seco.
- No instale el dispositivo cerca de ninguna fuente de calor o fuego tales como calefactores, estufas o incluso amplificadores que produzcan calor.
- Proteja el cable de ser pinzado o pisado.
- Únicamente utilice accesorios especificados por WORK PRO
- Desenchufe el dispositivo si no va a ser utilizado en largos periodos de tiempo.



51ZEN170